

# GENERAL FITTING GUIDE for PULL-UP BASIN WASTE

1. Identify that all components are present prior to installation.
2. Fit the optional foam washer (2) to the waste flange (1). If preferred, bed in the waste flange to the basin with a good clear silicone sealant. This should compensate for any slight moulding imperfections that may be present around the waste area.
3. Fit the large rubber seal (3) to the underside of the basin and secure by tightening the waste body (4) onto the flange's thread.
4. Place the pull-up knob & shroud assembly (11) onto the basin & secure using the small foam washer (10), metal plate (9) & retaining nut (8) on the underside of the basin.
5. Use pop-up swivel connection joint (6) to connect the vertical (7) and horizontal (5) connecting rods.
6. Check all joints & connections for any leaks.

## COMPONENTS

1. WASTE FLANGE
2. FOAM WASHER
3. LARGE RUBBER SEAL
4. WASTE BODY
5. HORIZONTAL CONNECTING ROD
6. SWIVEL CONNECTION JOINT
7. VERTICAL CONNECTING ROD
8. RETAINING NUT
9. METAL PLATE
10. FOAM WASHER
11. PULL-UP KNOB & SHROUD

